

Product protocol for carwash maintenance



STEP 1

FLOOR CLEANING

Floor Cleaner Forte at 5-10% (1/20 – 1/10)

1. Spray the surfaces.
2. Let it soak for 5-15 minutes depending the degree of dirt.
3. Rinse thoroughly (HP) after application

Floor Cleaner Ultra can also be used for automatic scrubber-dryer machine: 1-5% (100-500 ml in 10L). Don't use on soft floors or aluminium.



STEP 2

CONSTRUCTION CLEANING

Daily maintenance

Sanifresh at 5-10% (1/20-1/10)

Renovation (every 3-4 months)

Pro 400 at 10-20% (1/10-1/5)

1. Spray on the dirty surface (or with brush) and let it soak. Never let the solution dry up.
2. Work loose stubborn dirt with a brush.
3. Rinse (HP) with clean water after use.



STEP 3

BRUSH CLEANING

DM Clean at 20% (1/5)

1. Spray on the dirty surfaces and let it soak for a few hours (night).
2. Rinse (HP) with clean water after use.



STEP 4

CLEANING OF THE PIPES

Kenochlor at 50% (1/2)

1. Let it circulate with the water for approx. 10 minutes.
2. Let the Kenochlor circulate in the pump at 100% for 25 minutes. Check if all the dirt is out of the pipes. You can check at the nozzles. If not, continue with cleaning the system with Kenochlor.
3. Let water circulate in the system for approx. 15 minutes to assure that all the chemistry (Kenochlor) is out of the system.
4. Start to use the car cleaning chemicals.