



Strong alkaline concentrated CIP cleaner

Product Description

DM Clean Ultra is a strong alkaline concentrated CIP cleaner for the entire food industry.

Properties

DM Clean Ultra is used in CIP installation, cooking baths, pasteurizers and dishwashers. DM Clean Ultra is especially developed to be used at high temperatures.

Direction of use

Rinse before application.
Let circulate a 0.5-2% solution of DM Clean Ultra at a temperature of 50-90°C during 10-20 minutes.
Rinse with clean water.

Specifications

Physical state	Liquid
Colour	Clear
pH	ca. 12.5 (1%)
Density	ca. 1.3 kg/l
Solubility in water	100 %

Storage and Disposal

Protect from freezing. Keep at temperature not exceeding 50 °C. Keep container closed when not in use. Dispose in a safe manner according to local / national regulations.

Safety instructions for the user

Do not use on aluminum and on alkaline sensitive materials.
Avoid contact between alkaline and acid products.
Always test the product first on a small surface.
Consult your CID LINES sales' person for a suitable cleaning- and disinfecting program that is adjusted according to the contamination and the specific conditions of the company.

Before use, please check the MSDS.

Not all CID LINES products are available in all countries. For information about availability of a specific product, please contact your CID LINES dealer.

CID LINES

Believe in hygiene!

Waterpoortstraat 2, 8900 Ieper (Belgium)
T +32 (0)57 21 78 77 • F +32 (0)57 21 78 79
info@cidlines.com • www.cidlines.com

