Version: D

Date of Update: 4/05/2015

# Acid cleaner and disinfectant

# **Product Description**

Acid cleaner and disinfectant for CIP installations, milking installations and milk cooling tanks. Tested according to EN1276 Norm.

# **Properties**

Active substance according to regulation (EU) no. 528/2012: hydrogen peroxide (cas 7722-84-1): 38g/I Water soluble solution. For use in PT4 (biocide for food industry). For professional use.

## Direction of use

#### Cleaning:

- Rinse the equipment with cold to middle hot drinking water.
- Let circulate a 0.5% (50ml per 10 liters) solution of Pho Cid Ultra.
- Rinse with sufficient drinking water.

### Disinfection (Bactericidal):

- First clean the equipment with middle hot drinking water.
- Disinfect with a dosage of 0.5% Pho Cid Ultra (50ml per 10 liters) during minimum 15 minutes at a temperature of 40°C.
- Rinse with sufficient drinking water.

# **Specifications**

Physical state Liquid
Colour colourless
pH ca 2 (1%)
Density ca 1.15 kg/l

## Storage and Disposal

Keep only in the original container in a cool, well ventilated place. Keep container closed when not in use. Do not store in corrodable metal. Dispose in a safe manner in accordance with local/national regulations. Read the enclosed instructions before use. Reuse of packaging is prohibited. Disposal of packaging: The packaging has to be eliminated as dangerous waste under the responsibility of the holder of the waste. Do not throw on sewers and watercourses.

## Safety instructions for the user

Keep out of reach of children.

Care should be taken to reduce the possibility of eye contact. In case of eye contact, flush the eyes with copious amount of water and seek medical advice. In case of ingestion, seek medical advice. Call the anti-poison center. In case of inhalation, assure fresh air breathing. Allow the victim to rest. Seek medical attention immediately. In case of skin contact, remove affected clothing and wash all exposed skin area with mild soap and water, followed by warm water rinse. Seek medical advice.

Please check the MSDS.

Use biocides safely. Before use, read the label and the information concerning the product.



Waterpoortstraat 2, 8900 IEPER, Belgium. T +32 (0)57 21 78 77 • F +32 (0)57 21 78 79 • www.cidlines.com